


# SOFTY 1 Memory Map



## Notes:

- A7 driving the 8154 M/I/O pin is inverted hence RAM and I/O are swapped from normal.
- The 8154 repeats 4 times because of incomplete address decoding, typically addressed as shown here.
- Only half of 'Working RAM' is displayed on the screen at any one time.